




Ecological impact of a sapphire watch cover

Analysis in 3 parts:


1. Impact of sapphire *vs* other parts
2. Analysis of sapphire production environmental footprint
3. How to reduce the footprint ?




Sapphire
vs
other parts



Definition




Literature data [1]




[1] David Weber, HE-Arc “Case study of the ecological impact of a typical mechanical Swiss watch”, May 2022 [Link](#)

Calculating real embodied energy of sapphire



Calculating real embodied energy of sapphire






28%

average sapphire yield in watch industry


Calculating real embodied energy of sapphire



Flat

requires growing ~16g of Verneuil sapphire

~8 kWh



1 kg CO₂

@ CH average 89g/kWh



4 kg CO₂


@ World average 475g/kWh



Dome

requires growing ~73g of Verneuil sapphire

~36 kWh



3 kg CO₂

@ CH average 89g/kWh



17 kg CO₂

@ World average 475g/kWh

Real embodied energy of sapphire - by growth methods




	Energy for raw material kJ/g	Scrapping factor %	Form factor yield %	Yield of cores %	Slicing yield %	Combined yield %	Energy for final product kJ/g
Current growth methods with manual quality control							
Verneuil	1'800	10	42	87	85.1	28	6'431
Kyropoulos	923	4	34	95	85.1	26	3'498
HEM	360	5	45	90	85.1	33	1'099
Averages	1'028	6	40	91	85.1	29	3'676

➔ Effective embedded energy is ~3'600 KJ/g


Revised data taking into account sapphire yield

Literature data
for watch with DOMED
sapphire cover




**7 times
more energy**

Revised analysis, accounting for sapphire production yield
for DOMED cover



for FLAT cover



● Sapphire cover
● All other parts

*Assuming a Verneuil sapphire growth method



**Reducing the watch industry footprint,
implies improving, first of all,
the sapphire processing.**



How can we process sapphire smarter?


Adopt Industry 4.0 approach:

- Digital Quality control
- Coring optimisation
- Wafering optimisation
- Dome orientation


1. Smart coring



Non-processed crystal




Digital twin



Coring optimised for max yield

2. Smart wafering™

Pre-calculated core offset brings more defect-free préparages






2. Smart wafering™

Core to slice for préparages
Ø 23 mm, Th 2.0, Gap 1.0 mm

Traditional slicing
21 defect-free préparages


Smart slicing, offset 0.8 mm
23 defect-free préparages

→ + 2 préparages
+ 9.5% yield



3. Dome orientation

Avoiding material defects by flipping a domed piece



→ +4.2% yield

Modelling the impact of introducing Digital Quality Control


	Energy for raw material kJ/g	Scrapping factor %	Form factor yield %	Yield of cores %	Slicing yield %	Combined yield %	Energy for final product kJ/g
--	------------------------------------	--------------------------	---------------------------	------------------------	-----------------------	------------------------	-------------------------------------

Averages of 3 major growth methods controlled manually

Averages	1'028	6	40	91	85.1	29	3'676
----------	-------	---	----	----	------	----	-------

Impact of digital quality control (DQC)

ppt	—	-1 ppt	+5 ppt	+2 ppt	+3 ppt		
Average including DQC		5	45	93	88	35	2'933



Impact of digital quality control at the scale of the Swiss watch industry (21 millions watch covers/year)

Reduction in embodied energy, assuming an average cover weight is 5 grams	7.8 E+10 kJ
Reduction in CO2, assuming a worldwide average conversion factor of 475g CO ₂ per kWh	10'000 tons CO ₂

Modelling the impact of introducing Digital Quality Control



10'000 cars

or



town of 2'300 population


7.8 E+10 kJ

10'000 tons CO₂



Scientific Visual vision: **Produce Smarter to Impact Less**

Produce Smarter to Impact Less



Scientific Visual supplies smart processing equipment


for Sapphire / Ruby, Spinel, CaF_2 , LT/LN, Quartz, LBO, KTP



SapphiroScan™
for préparages



SapphiroScope™
for HEM and cores



TotalScan™
for X-large crystals

Contact



Frédéric Falise

+41 79 217 1210

frederic.falise@scientificvisual.ch

Scientific Visual

Automated
crystal inspection tools

Chemin du Closel 5

Renens VD 1020

Switzerland

www.scientificvisual.ch